


Model No. UC030G CORDLESS CHAIN SAW



Model No.UC030G CORDLESS CHAIN SAW

Obj. č.	Obj. č.	Popis	Možn ost zá měny	Množ ství	Nový/ Starý	Poznámka 1	Poznámka 2
001	327F81-8	FRONT HANDLE		1			
002	911218-7	Pan Head Screw M5x14=new922 217-4		4			
003	122K21-9	TANK CAP ASSEMBLY		1		v	
C10	213A77-4	O-RING 29.5		1			
004	4133J6-1	DUST COVER		1		protiprachov	
005	266326-2	šroub 4x18=new265995-6		9			
006	1831N9-2	Housing set		1		pouzdro	
C10	8091S4-6	Caution label		1			
006		INC. 45					
007	911118-1	šroub M4x12		2			
008	4133G1-0	FRONT HAND GUARD RETAINER		1		chr	
009	620S23-2	INDICATION CIRCUIT		1		obvod	
010	620P60-8	CONTORLER		1		ovl	
011	620S22-4	SWITCH CIRCUIT		1		obvod	
012	232850-7	Torsion spring 10		1		pru	
013	413C93-0	Switch lever		1		p	
014	141V01-2	Lock off lever complete		1		p	
015	650049-6	Switch C3JR-1A-PAXD5		1		vyp	
016	911228-4	šroub M5x18		3			
017	4133F9-7	MOTOR HOUSING		1		sk	
018	266490-9	Pan head tapping screw 2X6		3			
019	687H54-8	STOPPER		1		doraz	
020	652031-1	Pan head screw M3X6		3			
021	620P43-8	CONTROLLER B		1		ovl	
022	629D24-7	STATOR		1		stator	
023	4133G3-6	BAFFLE PLATE		1		deska	
024	266326-2	šroub 4x18=new265995-6		2			
025	210311-7	BALL BEARING 698ZZ		1			
026	519915-5	Rotor assembly		1		rotor	
026		INC. 25,27					
027	210274-7	Ball bearing 6000DDW		1			
028	422C81-6	OIL TUBE 3-154		1		olejov	
029	266427-6	Binding head tapping screw 4X1 2		2			
030	142857-4	Oil pump complete		1			
031	961011-9	zajišťovací kroužek		1		zaji	
032	226884-0	Worm gear		1		p	
033	422C80-8	OIL TUBE 3-117		1		olejov	
034	231975-4	pružina DCS230T/UC3020A=old0 21245060		1		pru	
035	452666-6	Nipple		1			
036	632V23-8	Terminal unit		1		koncov	
037	652031-1	Pan head screw M3X6		2			
038	266326-2	šroub 4x18=new265995-6		5			
040	1830H3-6	Terminal box set		1		svorkovnice	
C10	263005-3	vymezovací čep 6		2			
041	911228-4	šroub M5x18		4			
042	232956-1	TORSION SPRING 10		1		pru	

043	4133G8-6	SWITCH LEVER		1	p	
044	650057-7	Switch D2SW-P01L30-3M-C2(S)		1	sp	
045	1831N9-2	Housing set		1	pouzdro	
C10	8091S4-6	Caution label		1		
045		INC. 6				
046	137318-7	Housing base assembly		1	obal	
C10	263002-9	vymezovací čep 4		1		
047	4133G0-2	FRONT HAND GUARD		1	p	
048	313667-8	HAND GUARD GUIDE		1	vod	
049	232955-3	COMPRESSION SPRING 5		1	pru	
050	1411X1-4	LINK PLATE COMPLETE		1	deska	
051	232452-9	Compression spring 7		1	pru	
052	347E17-5	BRAKE BAND COMPLETE		1	kompletn	
053	162E14-8	BRAKE DRUM		1	brzdov	
054	213060-5	O-ring 10		1	o-krou	
055	227C36-4	SPROCKET8		1	ozuben	
056	961013-5	zajišťovací kroužek		1	zaji	
057	347E15-9	SPIKE BUMPER		1	ozub	
058	266034-5	šroub = old 933417		2		
059	4133H5-9	GUARD A		1	kryt a	
060	4133H4-1	GUARD B		1	kryt b	
061	347924-2	Chain catcher		1	kryt	
062	266034-5	šroub = old 933417		1		
063	213594-8	O-ring 7		1	o-krou	
064	227744-9	Helical gear 18		1	kolo=old 226693-7 1 85213250 18121325 0 EA3500S EA4300F E A2136 PS32C PS35C PS420SC PS6100H	
065	4133G5-2	GEAR COVER		1	kryt p	
066	347E16-7	TENSION SLIDE		1	nap	
067	227743-1	Helical gear 11		1	nap	
068	266034-5	šroub = old 933417		1		
069	266034-5	šroub = old 933417		3		
070	4133H0-9	BRAKE COVER		1	kryt brzdy	
071	422C82-4	CHIP GUIDE		1		
072	4133G9-4	INNER COVER		1		
073	4133G6-0	GUARD C		1		
074	4133G7-8	GUARD D		1		
075	137335-7	Sprocket cover assembly		1	kryt	
075		INC. 71-74				
076	8151R7-3	Name plate UC030G		1		
077	8151R9-9	Serial No. label UC030G		1		
A01	1915Y7-3	GUIDE BAR 16 SET		1		
A02	D-70960	FILE HOLDER SET 4.8MM(3/16")		1		
A03	4133L9-9	GUIDE BAR CASE 465		1		
A04	1916A1-3	SAW CHAIN 16 SET		1		
A05	782023-7	Wrench 13-16		1	*	
A05-1	782042-3	BOX WRENCH 13	O	1		
E01	8097C3-2	Sound label		1		
F02	1915Y7-3	GUIDE BAR 16 SET		1		
F03	1915Y8-1	GUIDE BAR 18 SET		1		
F04	1915Y9-9	GUIDE BAR 20 SET		1		

F05	1916A0-5	GUIDE BAR 20 SET		1			
F06	1916A1-3	SAW CHAIN 16 SET		1			
F07	1916A2-1	SAW CHAIN 18 SET		1			
F08	1916A3-9	Saw chain 20 set		1			
F09	1916A4-7	SAW CHAIN 20 SET		1			
F10	1916A5-5	SPROCKET 8 SET		1			

Prosím uveďte objednáací číslo dílu v objednávce

Datum tisku 22. 10. 2025